



Vuelift

Residential
Elevator

Owner's
Manual

 savaria.

IMPORTANT

Ensure that only an authorized Savaria Dealer installs and services the Vuelift Residential Elevator. Under no circumstances is anyone other than a dealer with Savaria training and authorization to install, adjust, service or modify any mechanical or electrical device on this equipment. Failure to follow this warning can result in safety system compromises or defeat; this can result in serious injury or death. Savaria accepts no liability for property damage, warranty claims or personal injury, including death, in this circumstance.

Passenger safety is the result of countless details in the equipment’s design, manufacture, and installation. After installation, reliable operation and continual safe operation requires regular service and inspection at least twice per year, or more frequently where usage, environment, or local jurisdiction requires. As the Owner, you are responsible for ensuring that regular service and inspections occur in a timely manner.

Refer to this manual for specifications, operating instructions and maintenance of the Vuelift Residential Elevator.

Upon completion of installation, the dealer must provide you with the following information and ensure it is recorded in this manual. In addition, either the dealer or you must keep any service and/or maintenance records in the Maintenance Record section of this manual.

WARRANTY

Ensure your Savaria Dealer provides you with a copy of the manufacturer’s limited parts warranty and documentation relating to any Dealer labour warranty.

FOR OWNER’S RECORDS

Customer Name: _____

Installing Dealer: _____

Dealer’s Telephone Number: _____

Date Installed: _____

Serial/Job Number: _____


TABLE OF CONTENTS

TO ENSURE SAFE OPERATION	4
1. DESCRIPTION	5
2. GENERAL SPECIFICATIONS	6
3. OPERATION	9
4. SAFETY FEATURES	10
Safety Brakes	10
Emergency Stop	10
Battery Lowering System and Manual Lowering Device	10
5. CLEANING	11
Washing	11
Dusting	11
Polishing	11
Neutralizing Static Electricity	12
Cleaners	12
6. DIAGNOSTICS	13
7. MAINTENANCE	14
Maintenance Schedule	15
Maintenance Record	16
Maintenance Procedures	17

TO ENSURE SAFE OPERATION

To ensure safe operation of this equipment, pay careful attention to the important notes below.

- Read this manual carefully before using the equipment.
- To prevent accidents, adhere strictly to the instructions and keep clear of moving parts at all times.
- Be aware of hazardous space between the hall door and car, especially for small children.



- Follow instructions on all equipment labels at all times. Replace any damaged labels immediately.
- Ensure that only qualified personnel perform maintenance and service on the unit.
- When replacing parts, be sure that only genuine Savaria parts are used.
- This unit is intended for use by a mature person who understands its proper operation as set out in this manual.



WARNING

At no time should children under the age of 16 use the elevator/lift while unsupervised.

- Prior to operation, make sure that:
 - All doors and gates are locked and secure.
 - All areas in and around the lift are clear of any obstructions.
 - All lights are functioning properly.
- Test your keys and emergency stop button every month.

1. DESCRIPTION

Figure 1 shows the components of the Vuelift Residential Elevator. Note that the round elevator is shown below; there is also an available octagonal shaped elevator.

Figure 1



2. GENERAL SPECIFICATIONS

Vuelift Specifications

Applied code	ASME 17.1/CSA B44 - Section 5.3
Load capacity	Round acrylic: 840 lb (381 kg) Octagonal acrylic: 840 lb (381 kg) Octagonal glass: 950 lb (432 kg) Octagonal+ glass: 950 lb (432 kg) Round+ glass: 950 lb (432 kg)
Maximum travel	55 ft (16.76 m)
Travel speed	Round acrylic: 32 ft/min (0.16 m/s) Octagonal acrylic: 32 ft/min (0.16 m/s) Octagonal glass: 40 ft/min (0.20 m/s) Octagonal+ glass: 40 ft/min (0.20 m/s) Round+ glass: 40 ft/min (0.20 m/s)
Maximum # of stops	6
Daily cycle	Normal: 40 Heavy: 80 Excessive: 150 Maximum starts in 1 hour on standard installation: 20
Noise level	65 dB
Temperature operating range	-10 °C to +40 °C (14 °F to 104 °F)
Pit depth	4 - 12 in (102 - 305 mm) No pit with optional short ramp
Overhead clearance	Round acrylic: 106 in (2.69 m) Round acrylic, optional short cab: 96 in (2.44 m) Octagonal acrylic: 106 in (2.69 m) Octagonal acrylic, optional short cab: 96 in (2.44 m) Octagonal glass: 108 in (2.74 m) Octagonal+ glass: 108 in (2.74 m) Round+ glass: 108 in (2.74 m)
Footprint	Round acrylic: 54 in (1.37 m) diameter Octagonal acrylic: 59.31 in x 45.5 in (1.5 m x 1.16 m) Octagonal glass: 59.31 in x 45.5 in (1.5 m x 1.16 m) Octagonal+ glass: 59.31 in x 45.5 in (1.5 m x 1.16 m) Round+ glass: 57.56 in (1.46 m) diameter

Cab (car)	<p>Round acrylic:</p> <ul style="list-style-type: none"> • Cab interior height (standard): 84 in (2.13 m) • Cab interior height (optional): 76.5 in (1.94 m) • Cab weight: 550 lb (250 kg) • Cab floor area: 13.09 sq ft (1.22 sq m) <p>Octagonal acrylic:</p> <ul style="list-style-type: none"> • Cab interior height (standard): 84 in (2.13 m) • Cab interior height (optional): 76.5 in (1.94 m) • Cab weight: 550 lb (250 kg) • Cab floor area: 12.83 sq ft (1.19 sq m) <p>Octagonal glass:</p> <ul style="list-style-type: none"> • Cab interior height: 84 in (2.13 m) • Cab weight: 1000 lb (455 kg) • Cab floor area: 12.83 sq ft (1.19 sq m) <p>Octagonal glass+:</p> <ul style="list-style-type: none"> • Cab interior height: 84 in (2.13 m) • Cab weight: 1200 lb (544 kg) • Cab floor area: 14.00 sq ft (1.31 sq m) <p>Round glass+:</p> <ul style="list-style-type: none"> • Cab interior height: 108 in (2.74 m) • Cab weight: 1200 lb (544 kg) • Cab floor area: 15.00 sq ft (1.4 sq m)
Power supply (circuit supplied by others)	30A, 230-V, single-phase, 50/60 Hz
Cab (car) lighting	15A, 115V, single-phase, 50/60 Hz
Suspension	<p>Type: Galvanized aircraft cable (2 x 3/8" diameter) Construction: IWRC 7 x 19 RHRL Nominal strength: 14,400 lb (6,545 kg) Weight of ropes: 0.243 lb/ft (3.616 g/cm) Travel cable weight: 0.228 lb/ft (3.393 g/cm)</p>
Drive train	<p>Type: Winding drum Motor (acrylic model): 1.5 HP with integrated brake Motor (silica glass model): 3.0 HP with integrated brake Transmission: Ultra-low vibration, 3-stage, right-angle, helical-bevel drive Motor control: Preprogrammed variable frequency drive Door interlocks: Xtronics</p>

Safety features	Emergency battery back-up for cab lighting and lowering Manual lowering Emergency alarm and stop switch Safety brakes Electrical circuit overspeed Pit run/stop switch and car top run/stop switch
Options	Optional configurations: Type 1, 2, 3 Optional colors: White, silver, or custom powder-coat frame (note that black is the standard color) Other options: Up to 6 stops, balcony attachment Savaria Link remote monitoring (Vuelift Micro-6 only)

3. OPERATION

- 1 Press the hall call button.
- 2 When the hall call door unlocks, open the hoistway door.
- 3 Open the car door and enter the elevator.
- 4 Close the hoistway door and then close the car door.
- 5 Press a button on the Car Operating Panel (COP) to select a floor.
- 6 When you arrive at the selected floor, open the car door and exit the elevator.
- 7 Close the car door and then close the hoistway door.

Note that there is a keypad phone located on the COP for use in an emergency..

- To dial a phone number, press the red **ON/OFF** button on the keypad to turn on the phone.
- Dial the phone number.
- Press the blue **VOL** key on the keypad to raise or lower the volume.
- Press the red **ON/OFF** button on the keypad to turn off the phone.



Figure 2




Figure 3

4. SAFETY FEATURES

Safety Brakes

The safety brakes (safeties) stop the lift in the event of cable failure.

During operation, cable tension keeps the brake up so the cam does not interfere with the hoistway rails.

If a cable failure occurs, the brake mechanism comes down and the brake cam stops movement of the lift.



Figure 4

Emergency Stop

Actuating the red Emergency Stop switch during travel will stop the elevator immediately and activate the alarm. Toggle the Emergency Stop switch to return the elevator to normal operation.

Battery Lowering System and Manual Lowering Device

If a power failure occurs, a battery lowering system will bring the Vuelift to the bottom level.

If the battery fails while operating, there is a manual lowering device that can be used to bring the Vuelift to the bottom landing level as described below.

- 1 Turn off the main power disconnect.
- 2 Remove the aluminum snap cap cover on the right side of the top floor landing door (above the top floor ring) using a $\frac{3}{4}$ " open-end wrench.
- 3 Insert the manual lowering crank into the hole provided in the rail.
- 4 Turn the wheel until the unit is at the landing level.
- 5 Use the special emergency key to manually open the landing door.

NOTE

*The manual lowering device is for **emergency use** only. After use of any emergency function (access key or manual lowering device), ensure that all doors/gates are secure and locked. While the emergency function is in use, **DO NOT** leave the area unattended.*

5. CLEANING



Under no circumstances should you ever attempt to remove panels for cleaning!

Clean **acrylic panels** with a mild soap and water solution or with acrylic cleaner (see the list on the next page). A few precautions must be taken to ensure a long operating life and to maintain the acrylic panel clarity on your unit.

NOTE

DO NOT use any cleaning product on acrylic that contains ammonia or petroleum. This includes Windex[®] and most traditional glass cleaners.

Clean **glass panels** using a normal glass cleaner such as Windex[®] or equivalent.

Washing (Acrylic Panels)

Wash the acrylic panels with a solution of mild soap or detergent and lukewarm water. Use a clean soft cloth, applying only light pressure. Rinse with clean water and dry by blotting with a damp cloth or chamois.

NOTE

DO NOT use window cleaning sprays, kitchen scouring compounds or solvents such as acetone, gasoline, benzene, alcohol, carbon tetrachloride, or lacquer thinner. These can scratch the sheet's surface and/or weaken the sheet causing small surface cracks called "crazing."

Dusting (Acrylic Panels)

Dust acrylic panels with a soft, damp cloth or chamois. Dry or gritty cloths may cause surface scratches and create a static electric charge on the surface (refer to the section on Neutralizing Static Electricity on the next page).

Polishing (Acrylic Panels)

Protect the acrylic panels and maintain their surface gloss by occasional polishing with a good plastic cleaner and polish (refer to the section on Cleaners for a list of acceptable cleaners and polishes).

Apply a thin, even coat with a soft clean cloth and polish slightly with cotton flannel or a microfiber towel. Then wipe with a damp cloth to help eliminate electrostatic charges that can attract dust particles.

Neutralizing Static Electricity (Acrylic Panels)

A static electrical charge can develop on the acrylic panels during handling and processing. This is not unique to the acrylic panels, but is common to many materials, particularly plastics.

When the paper or film masking is stripped off the acrylic sheet, a static charge is created on the sheet surface. Static electricity attracts dust, chips, etc. floating in the air or on nearby work surfaces and holds these contaminants tightly to the surface. A compressed air gun will remove some of this surface dirt, but much of it continues to cling to the sheet.

Several anti-static cleaners for plastics are also available which will reduce static electricity and dust attraction. Wiping with a soft damp cloth or chamois is all that is necessary to keep the acrylic panels dust-free between applications of these cleaners.

NOTE

A de-ionizing tool can be used during installation to eliminate a majority of the static electricity (causes the dust to fall away).

Cleaners

Cleaners which **MAY BE USED** for acrylic panels:

- Plexus® (Anti-Static Cleaner)
- Novus® #1 Acrylic Cleaner and Polish
- ATM Mirage Glass and Acrylic Cleaner
- Zep® Commercial Glass Cleaner (must state for use on Plexiglas®)
- Plexi-Clean (Anti-Static Cleaner)
- Prist Aerospace Anti-Static Acrylic, Plastic & Glass Cleaner
- Cleaners which explicitly state "Safe for use with plastics and acrylic"

Cleaners which **MAY NOT BE USED** for acrylic panels:

- Windex® Glass Cleaner
- Sprayway Ammonia-Free Glass Cleaner
- Goo-Gone®

For glass panels, use a normal glass cleaner such as Windex® or equivalent.

These above lists are for reference only and are not comprehensive. If you have any questions about the acceptability of a specific cleaner, please contact your authorized dealer.

Note that damage caused by inappropriate cleaners and techniques is not covered under warranty.

6. DIAGNOSTICS

Diagnostic beep codes are provided on the Hall Calls to help you diagnose a problem. All beep codes that begin with a long beep (on for 2 seconds) are Service codes (contact your authorized Savaria dealer).

If you press a Hall Call button and it beeps but the car doesn't move, refer to the information in the following table.

Beep code	Action to take
Service codes	
1 long beep (2 seconds) followed by 1 short beep (1/2 second)	Contact your authorized Savaria dealer for service. There is a problem in one of the following areas: overload trip, run timer trip, main safety chain open, door lock fault, or auto shutdown counter.
1 long beep (2 seconds) followed by 2 short beeps (1/2 second)	Contact your authorized Savaria dealer for service. There is a problem with re-level shutdown or the low pressure switch is activated.
1 long beep (2 seconds) followed by 3 short beeps (1/2 second)	Contact your authorized Savaria dealer for service. There is a selector fault, selector encoding error, or position error.
User codes	
1 short beep (1/2 second)	Make sure the "Stop" switch in the car in the Run position. Check that the car gate is closed.
2 short beeps (1/2 second)	Check that the landing door is closed.
3 short beeps (1/2 second)	Manually open and close the gate.

7. MAINTENANCE

Vuelift elevators are designed to require minimal maintenance.

A 6-month inspection of certain components is required to maintain the Vuelift Factory Warranty. The first required service of the drive train components (motor/gearbox, drums, etc.) is after 2,000 operational hours (approximately 120,000 trips).

Note that rail lubrication is NOT ALLOWED for the Vuelift hoistway or car rails.

The items that need to be checked during the 6-month inspection are listed in the table on the next page.

NOTE

*The 6-month inspection and all maintenance procedures **must** be performed by a Qualified Technician. Contact your Authorized Dealer.*

IMPORTANT: Please test the phone in your elevator during every maintenance. If the phone is inactive, please shut down the elevator until the phone line is active.

Maintenance Schedule

Verification by technician	Frequency
INSIDE CAR <ul style="list-style-type: none"> • Car interior • Car controls and panel • Leveling, stop, acceleration and deceleration • Car door operation • Ride floor to floor • Car lights and ventilation • Restricted opening device mechanism 	6 months
OUTSIDE HOISTWAY <ul style="list-style-type: none"> • Hall call station and lights • Hoistway doors • Unlocking device 	6 months
MACHINE ROOM <ul style="list-style-type: none"> • Housekeeping • Trash, used parts, etc. • Controller and starter 	6 months
TOP OF CAR <ul style="list-style-type: none"> • Stop switch • Cleanliness • Top car guides • Guide rails • Traveling cable • Doors, hangers and locks • Hoistway cleaning • Other • Examine the ropes • Leaving car top 	6 months
PIT (IF APPLICABLE) <ul style="list-style-type: none"> • Stop switch and light • Cleaning • Bottom car guides • Traveling cable • Leaving the pit 	6 months
OVERSPEED (NEW CAR) <ul style="list-style-type: none"> • Overspeed belt • Overspeed system ELECTRICAL CIRCUIT OVERSPEED (ORIGINAL CAR) <ul style="list-style-type: none"> • Plastic flywheel and plastic flywheel gear • Plastic shaft bushings 	6 months
BRAKES <ul style="list-style-type: none"> • Safety brakes and motor brake • Safety brakes and motor brake (with full load) 	6 months 12 months

Maintenance Record

Date	Time	Reason for Call	Comments	Dealer

Maintenance Procedures

INSIDE CAR

Car Interior

- Examine the car interior for damage including the ceiling, handrails, door panels, lighting and floor. Tighten all fasteners in the car panel and replace as needed.

Car Controls and Panel

- Examine the condition of the car control panels and check the operation of all lights. Replace all burnt out lights.

Leveling, Stopping, Acceleration and Deceleration

- Run the car to each floor in both directions to observe the leveling accuracy, stopping, acceleration and deceleration. Adjust as needed.

Car Door Operation

- Observe the door for proper operation including smooth movement, starts and stops, and alignment.

Ride Floor to Floor

- Run the car from floor to floor and observe for smooth travel and unusual noises. Adjust or repair as needed.

Car Lights and Ventilation

- Verify proper operation of the car emergency light and ensure adequate ventilation.

Restricted Opening Device Mechanism

- Examine the restricted opening device mechanism (if applicable) for proper operation and adjust as needed.

OUTSIDE HOISTWAY

Hall Call Stations and Lights

- Examine the hall stations for condition and replace all burnt out lights. Observe operation of the audible signal when the Emergency Stop is activated.

Hoistway Doors

- Examine the door panel and clearance between the panel and entrance frames. Examine proper interlock functionality and operation. Adjust as needed.

Unlocking Device

- Examine the hoistway door unlocking device for damage. Repair or adjust as needed.

MACHINE ROOM

Housekeeping (Required with Remote Controller Option)

- Clean the machine room floor to prevent slipping and trip hazards, fire hazards and contamination of the equipment. Ensure the machine room is not being used for storage and inform the customer of any violation.

Trash, Used Parts and Oil

- Ensure that all trash is discarded after maintenance is complete.

Controller and Motor Starter

- Examine the controller and motor starter for:
 - Cleanliness
 - Condition of contacts and remaining contact material
 - Fuses for correct size and fit in holders and corrosion in fuseholder
 - Relays for worn shunts and signs of overheating
 - Evidence of overheating

TOP OF CAR

Stop Switch

- Verify the car will not run with the stop switch in the STOP position.

Cleanliness

- Clean all debris from the car top.

Top Car Guide

- Examine car rail to hoistway rail conditions at the car top. Note any abnormal wear patterns or changes in alignment.

Guide Rails

- Examine the car rails for loose fastenings and fit at all joints.

Traveling Cables

- Examine the traveling cables for wear, chafing, kinking and alignment. Examine the attachment points for secure fastening and looseness.

Door Hangers, Locks, etc.

- Verify the interlock is functioning properly.
- With the door open, attempt to move the car using the hall call and COP buttons.
- Observe the door closing for any roughness in bearings, inconsistent operation, or misalignment.

Hoistway Cleaning

- Clean dirt and trash from all horizontal surfaces including the car and entrance sills.

Other

- Observe any hoistway problems that should be addressed such as:
 - Unauthorized equipment installed in the hoistway
 - Damage to the hoistway enclosure which would affect its fire resistance rating
 - Evidence of intentional acts
 - Any evidence of unauthorized people entering the hoistway

Examine the Ropes

- Examine the car ropes for equal tension, and visually inspect for any frays or deformation of the ropes which would negatively impact their strength.

Leaving the Car Top

- Clean up and dispose of debris properly. Return the car to normal operation and the stop switch to the RUN position.

PIT (IF APPLICABLE)

Stop Switch

- Examine the operation and condition of the stop switch. Repair as needed.

Cleaning

- Clean the pit. Examine the bottom level landing sill and clean as needed.

Bottom Car Glides

- Examine car rail to hoistway rail conditions at the car bottom. Note any abnormal wear patterns or changes in alignment.

Traveling Cables

- Examine the traveling cables for wear, chafing, kinking and alignment. Examine the attachment points for secure fastening and looseness.

Leaving the Pit

- Remove all tools and verify operation of the elevator.

OVERSPEED (NEW CAR)

Overspeed belt

- Make sure the overspeed belt is in good condition and that it has no frays or cuts. Check that the ends are secure.

Overspeed system

- Check for any signs of wear in the overspeed system. Remove any dust or dirt from the belt and pulleys. Do not use harsh chemicals on the overspeed components; use only mild detergents.

ELECTRICAL CIRCUIT OVERSPEED (ORIGINAL CAR)

Plastic Flywheel

- Check to ensure the plastic flywheel rotates during lift operation (gears are fully engaged).

Plastic Flywheel Gear

- Check for wear (ensure all teeth are present) and replace as needed.

Plastic Shaft Bushings

- Check for wear and replace as needed.

BRAKES

Verify proper operation of the safety brakes and the motor brake. Check with full load every 12 months.

Authorized Savaria Dealer

Vuelift Residential Elevator OWNER'S MANUAL

Part No. 001122
Rev. 17-m06-2020

Copyright © 2020

Savaria Concord Lifts, Inc.
2 Walker Drive
Brampton, Ontario, L6T 5E1, Canada
www.savaria.com

For service or questions about this product, please contact your installing dealer.

DEALER NAME: _____

DEALER PHONE: _____

